

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 0.7**

Carré conducteur 3/4"



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe. Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	94
1200.....	84.....	113
1400.....	98.....	132
1600.....	110.....	150
1800.....	124.....	169
2000	138	188
2200.....	152.....	207
2400.....	165.....	226
2600.....	179.....	249
2800.....	193.....	268
3000	207	287
3200.....	220.....	306
3400.....	234.....	325
3600.....	248.....	347
3800.....	262.....	366
4000	276	385
4200.....	290.....	404
4400.....	303.....	424
4600.....	317.....	452
4800.....	331.....	471
5000	345	491
5200.....	358.....	511
5400.....	372.....	530
5600.....	386.....	551
5800.....	400.....	570
6000	414	590
6200.....	427.....	610
6400.....	441.....	629
6600.....	455.....	652
6800.....	468.....	672
7000	482	692
7200.....	496.....	712
7400.....	510.....	732
7600.....	524.....	757
7800.....	538.....	777
8000	552	797
8200.....	565.....	817
8400.....	579.....	837
8600.....	593.....	864
8800.....	607.....	884
9000	620	904
9200.....	634.....	924
9400.....	648.....	944
9600.....	662.....	969
9800.....	676.....	989
10000	690	1009

www.hytorc-services.com

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 1**

Carré conducteur 3/4"



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe. Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	177
1200.....	84.....	213
1400.....	98.....	248
1600.....	110.....	283
1800.....	124.....	319
2000	138	354
2200.....	152.....	390
2400.....	165.....	426
2600.....	179.....	463
2800.....	193.....	499
3000	207	535
3200.....	220.....	571
3400.....	234.....	606
3600.....	248.....	641
3800.....	262.....	676
4000	276	712
4200.....	290.....	747
4400.....	303.....	782
4600.....	317.....	817
4800.....	331.....	853
5000	345	888
5200.....	358.....	922
5400.....	372.....	956
5600.....	386.....	990
5800.....	400.....	1023
6000	414	1057
6200.....	427.....	1092
6400.....	441.....	1126
6600.....	455.....	1161
6800.....	468.....	1195
7000	482	1230
7200.....	496.....	1263
7400.....	510.....	1297
7600.....	524.....	1330
7800.....	538.....	1364
8000	552	1398
8200.....	565.....	1432
8400.....	579.....	1466
8600.....	593.....	1500
8800.....	607.....	1534
9000	620	1568
9200.....	634.....	1603
9400.....	648.....	1637
9600.....	662.....	1672
9800.....	676.....	1706
10000	690	1741

www.hytorc-services.com

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 3**

Carré conducteur 1''



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe. Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	406
1200.....	84.....	487
1400.....	98.....	568
1600.....	110.....	636
1800.....	124.....	716
2000	138	795
2200.....	152.....	875
2400.....	165.....	954
2600.....	179.....	1043
2800.....	193.....	1123
3000	207	1203
3200.....	220.....	1283
3400.....	234.....	1363
3600.....	248.....	1483
3800.....	262.....	1566
4000	276	1648
4200.....	290.....	1730
4400.....	303.....	1813
4600.....	317.....	1870
4800.....	331.....	1952
5000	345	2033
5200.....	358.....	2114
5400.....	372.....	2196
5600.....	386.....	2273
5800.....	400.....	2354
6000	414	2435
6200.....	427.....	2516
6400.....	441.....	2597
6600.....	455.....	2703
6800.....	468.....	2785
7000	482	2867
7200.....	496.....	2949
7400.....	510.....	3031
7600.....	524.....	3145
7800.....	538.....	3227
8000	552	3310
8200.....	565.....	3393
8400.....	579.....	3476
8600.....	593.....	3559
8800.....	607.....	3642
9000	620	3725
9200.....	634.....	3808
9400.....	648.....	3891
9600.....	662.....	4015
9800.....	676.....	4098
10000	690	4182

www.hytorc-services.com

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 5**

Carré conducteur 1" 1/2



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.
Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	692
1200.....	84.....	830
1400.....	98.....	969
1600.....	110.....	1111
1800.....	124.....	1257
2000	138	1403
2200.....	152.....	1544
2400.....	165.....	1685
2600.....	179.....	1826
2800.....	193.....	1967
3000	207	2108
3200.....	220.....	2251
3400.....	234.....	2393
3600.....	248.....	2536
3800.....	262.....	2678
4000	276	2821
4200.....	290.....	2962
4400.....	303.....	3102
4600.....	317.....	3243
4800.....	331.....	3384
5000	345	3525
5200.....	358.....	3664
5400.....	372.....	3804
5600.....	386.....	3943
5800.....	400.....	4083
6000	414	4223
6200.....	427.....	4359
6400.....	441.....	4495
6600.....	455.....	4631
6800.....	468.....	4767
7000	482	4903
7200.....	496.....	5037
7400.....	510.....	5170
7600.....	524.....	5303
7800.....	538.....	5437
8000	552	5570
8200.....	565.....	5705
8400.....	579.....	5839
8600.....	593.....	5974
8800.....	607.....	6108
9000	620	6243
9200.....	634.....	6375
9400.....	648.....	6508
9600.....	662.....	6641
9800.....	676.....	6774
10000	690	6907

www.hytorc-services.com

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 8**

Carré conducteur 1" 1/2



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.
Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	1039
1200.....	84.....	1247
1400.....	98.....	1455
1600.....	110.....	1668
1800.....	124.....	1886
2000	138	2104
2200.....	152.....	2321
2400.....	165.....	2538
2600.....	179.....	2755
2800.....	193.....	2971
3000	207	3188
3200.....	220.....	3405
3400.....	234.....	3622
3600.....	248.....	3838
3800.....	262.....	4055
4000	276	4271
4200.....	290.....	4487
4400.....	303.....	4703
4600.....	317.....	4918
4800.....	331.....	5134
5000	345	5349
5200.....	358.....	5561
5400.....	372.....	5774
5600.....	386.....	5986
5800.....	400.....	6198
6000	414	6411
6200.....	427.....	6621
6400.....	441.....	6831
6600.....	455.....	7041
6800.....	468.....	7251
7000	482	7461
7200.....	496.....	7667
7400.....	510.....	7872
7600.....	524.....	8078
7800.....	538.....	8283
8000	552	8489
8200.....	565.....	8693
8400.....	579.....	8897
8600.....	593.....	9101
8800.....	607.....	9305
9000	620	9510
9200.....	634.....	9712
9400.....	648.....	9914
9600.....	662.....	10115
9800.....	676.....	10317
10000	690	10519

www.hytorc-services.com

Tableau de conversion Pression - couple

Pression : Couple

Clé Hydraulique **AVANTI 10**

PSI : Bars Newton mètre

Carré conducteur 1" 1/2



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.
Vous obtiendrez les couples correspondants sur la clé.

1000	70	1336
1200.....	84.....	1603
1400.....	98.....	1870
1600.....	110.....	2139
1800.....	124.....	2410
2000	138	2681
2200.....	152.....	2960
2400.....	165.....	3238
2600.....	179.....	3517
2800.....	193.....	3795
3000	207	4074
3200.....	220.....	4352
3400.....	234.....	4630
3600.....	248.....	4908
3800.....	262.....	5186
4000	276	5464
4200.....	290.....	5735
4400.....	303.....	6006
4600.....	317.....	6277
4800.....	331.....	6548
5000	345	6819
5200.....	358.....	7094
5400.....	372.....	7370
5600.....	386.....	7645
5800.....	400.....	7920
6000	414	8196
6200.....	427.....	8471
6400.....	441.....	8747
6600.....	455.....	9022
6800.....	468.....	9298
7000	482	9573
7200.....	496.....	9844
7400.....	510.....	10115
7600.....	524.....	10386
7800.....	538.....	10657
8000	552	10927
8200.....	565.....	11201
8400.....	579.....	11474
8600.....	593.....	11747
8800.....	607.....	12020
9000	620	12293
9200.....	634.....	12566
9400.....	648.....	12839
9600.....	662.....	13112
9800.....	676.....	13385
10000	690	13658

www.hytorc-services.com

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 20**

Carré conducteur 2" 1/2



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.
Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	2535
1200.....	84.....	3042
1400.....	98.....	3548
1600.....	110.....	4065
1800.....	124.....	4590
2000	138	5115
2200.....	152.....	5640
2400.....	165.....	6165
2600.....	179.....	6690
2800.....	193.....	7215
3000	207	7740
3200.....	220.....	8276
3400.....	234.....	8811
3600.....	248.....	9347
3800.....	262.....	9882
4000	276	10418
4200.....	290.....	10929
4400.....	303.....	11441
4600.....	317.....	11953
4800.....	331.....	12464
5000	345	12976
5200.....	358.....	13500
5400.....	372.....	14025
5600.....	386.....	14550
5800.....	400.....	15074
6000	414	15599
6200.....	427.....	16120
6400.....	441.....	16642
6600.....	455.....	17163
6800.....	468.....	17684
7000	482	18206
7200.....	496.....	18740
7400.....	510.....	19274
7600.....	524.....	19808
7800.....	538.....	20342
8000	552	20876
8200.....	565.....	21375
8400.....	579.....	21874
8600.....	593.....	22373
8800.....	607.....	22872
9000	620	23371
9200.....	634.....	23935
9400.....	648.....	24499
9600.....	662.....	25064
9800.....	676.....	25628
10000	690	26193

www.hytorc-services.com

Tableau de conversion Pression - couple

Clé Hydraulique **AVANTI 35**

Carré conducteur 2" 1/2



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.
Vous obtiendrez les couples correspondants sur la clé.

Pression : Couple

PSI : Bars Newton mètre

1000	70	4521
1200.....	84.....	5425
1400.....	98.....	6329
1600.....	110.....	7165
1800.....	124.....	8060
2000	138	8956
2200.....	152.....	9852
2400.....	165.....	10747
2600.....	179.....	11739
2800.....	193.....	12642
3000	207	13545
3200.....	220.....	14448
3400.....	234.....	15351
3600.....	248.....	16391
3800.....	262.....	17301
4000	276	18212
4200.....	290.....	19123
4400.....	303.....	20033
4600.....	317.....	20986
4800.....	331.....	21899
5000	345	22811
5200.....	358.....	23723
5400.....	372.....	24636
5600.....	386.....	25735
5800.....	400.....	26654
6000	414	27573
6200.....	427.....	28492
6400.....	441.....	29411
6600.....	455.....	30414
6800.....	468.....	31335
7000	482	32257
7200.....	496.....	33179
7400.....	510.....	34100
7600.....	524.....	35053
7800.....	538.....	35976
8000	552	36898
8200.....	565.....	37820
8400.....	579.....	38743
8600.....	593.....	39780
8800.....	607.....	40705
9000	620	41630
9200.....	634.....	42555
9400.....	648.....	43480
9600.....	662.....	44325
9800.....	676.....	45249
10000	690	46172

www.hytorc-services.com